

ON / OFF

QUICK START UP GUIDE Minijet FastPAD



Switch on: Push the coder 1 second Switch off: Push the coder 3 seconds Settings / adjustments: rotate the coder Settings validation: One push on the coder

Combi mode : To set humidity, press twice on

a I I





QUICK START UP GUIDE Minijet FastPAD



VULCAN

AUTO

MANU

TOOL BOX



